



CHANGE SHACKLE CODE - EKEY ONLY

NOTE: Keybox must be in eKEY inventory (My Keyboxes).

1. Tap My Keyboxes.
2. Tap the relevant keybox.
3. Tap **Program Keybox**
4. Under Keybox Settings, tap **Shackle Code**.
5. Enter a new shackle code and enter it again to confirm.
6. Tap **Save**.
7. Tap **Program**.
8. Enter the old shackle code.
9. When the Success! Message appears, tap Home icon to return to main menu.